

Dragon Breed
Irem, 1989

Dragon Breed
Option Switch Settings

DIP Switch No. 1 Settings								Option
1	2	3	4	5	6	7	8	
Number of Players								
Off	Off							3
On	Off							2
Off	On							4
On	On							5
Difficulty								
	Off	Off						Normal
	On	Off						Easy
	Off	On						Hard
	On	On						Very Easy
Credits Per Coin, Mode 2 (SW#3 of DIP SW#2 On)								
		Off	Off					Coin Mech A, 1 Coin 1 Credit
		On	Off					Coin Mech A, 2 Coins 1 Credit
		Off	On					Coin Mech A, 3 Coins 1 Credit
		On	On					Coin Mech A, 5 Coins 1 Credit
				Off	Off			Coin Mech B, 1 Coin 2 Credits
				On	Off			Coin Mech B, 1 Coin 3 Credits
				Off	On			Coin Mech B, 1 Coin 5 Credits
				On	On			Coin Mech B, 1 Coin 6 Credits
Credits Per Coin, Mode 1 (SW#3 of DIP SW#2 Off)								
	Off	Off	Off	Off				1 Coin 1 Credit
	On	Off	Off	Off				2 Coins 1 Credit
	Off	On	Off	Off				3 Coins 1 Credit
	On	On	Off	Off				4 Coins 1 Credit
	Off	Off	On	Off				5 Coins 1 Credit
	On	Off	On	Off				6 Coins 1 Credit
	Off	On	On	Off				1 Coin 2 Credits
	On	On	On	Off				1 Coin 3 Credits
	Off	Off	Off	On				1 Coin 4 Credits
	On	Off	Off	On				1 Coin 5 Credits
	Off	On	Off	On				1 Coin 6 Credits
	On	On	Off	On				2 Coins 3 Credits
	Off	Off	On	On				3 Coins 2 Credits
	On	Off	On	On				5 Coins 3 Credits
	Off	On	On	On				8 Coins 3 Credits
	On	On	On	On				Free Play

Notes:

1) Select Coin Mode 1 in case a single coin selector or two coin selectors

for coins of the same value are used.

2) Select Coin Mode 2 in case two coin selectors of coins of different

values are used.

DIP Switch No. 2 Settings								Option
1	2	3	4	5	6	7	8	
								Flip Picture

Off								No
On								Yes
								Cabinet Type

Off								Cocktail Table
On								Upright
								Coin Mode

								Mode 1
Off								Mode 2
On								
								Sound in Demo

								No
Off								Yes
On								
								Continue

								Yes
Off								No
On								
								Freeze Picture

								No
Off								Yes
On								
								Diagnostic Test

								No
Off								Yes
On								

(SW#7 is not labeled)

Note:

In the freeze picture mode, press 2P-Start button to freeze and 1P-

Start

button to restart the game.