

GYRUSS

-----

From: woodcock@crchh75b.bnr.ca (Gregg Woodcock)

Well what may have happened is that there was one PCB design for the standup and one for the cocktail machine. My cocktail machine has 2 volume controls and the "extra" DIP switches and the manual that I have (that says, "Gyruss cocktail table service manual") documents them both. The DIP switches (from the manual) are:

#### OPTIONAL DIP SWITCH SETTINGS

-----

##### 1. Dip Switch No.1 (8P Dip Switch)

^^[sic; no space]

Credits

v-----[sic; "0" instead of "o"]

| +-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+ |       |     |     |     |     |     |     |     |     |  |
|---------------------------------------------------------------|-------|-----|-----|-----|-----|-----|-----|-----|-----|--|
| C0in                                                          | Plays | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 |  |
| +-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+ |       |     |     |     |     |     |     |     |     |  |
| 1                                                             | 1     | Off | Off | Off | Off | Off | Off | Off | Off |  |
| 1                                                             | 2     | On  | Off | Off | Off | On  | Off | Off | Off |  |
| 1                                                             | 3     | Off | On  | Off | Off | Off | On  | Off | Off |  |
| 1                                                             | 4     | On  | On  | Off | Off | On  | On  | Off | Off |  |
| 1                                                             | 5     | Off | Off | On  | Off | Off | Off | On  | Off |  |
| 1                                                             | 6     | On  | Off | On  | Off | On  | Off | On  | Off |  |
| 1                                                             | 7     | Off | On  | On  | Off | Off | On  | On  | Off |  |
| 2                                                             | 1     | On  | On  | On  | Off | On  | On  | On  | Off |  |
| 2                                                             | 3     | Off | Off | Off | On  | Off | Off | Off | On  |  |
| 2                                                             | 5     | On  | Off | Off | On  | On  | Off | Off | On  |  |
| 3                                                             | 1     | Off | On  | Off | On  | Off | On  | Off | On  |  |
| 3                                                             | 2     | On  | On  | Off | On  | On  | On  | Off | On  |  |
| 3                                                             | 4     | Off | Off | On  | On  | Off | Off | On  | On  |  |
| 4                                                             | 1     | On  | Off | On  | On  | On  | Off | On  | On  |  |
| 4                                                             | 3     | Off | On  | On  | On  | Off | On  | On  | On  |  |
| FREE PLAY                                                     |       | On  | On  | On  | On  | On  | On  | On  | On  |  |
| +-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+ |       |     |     |     |     |     |     |     |     |  |

##### 2. Dip Switch No. 2 (8P Dip Switch)

Number of Spaceships

Game Type

| +-----+-----+-----+ |     |     | +-----+-----+-----+      |                |  |
|---------------------|-----|-----|--------------------------|----------------|--|
| Number              | SW1 | SW2 | Style SW3                | Players        |  |
| +-----+-----+-----+ |     |     | +-----+-----+-----+      |                |  |
| * 3                 | Off | Off | Table Off                | 1 or 2 Players |  |
| 4                   | On  | Off | Upright Off              | Only 1 Player  |  |
| 5                   | Off | On  | +-----+-----+-----+      |                |  |
| 256                 | On  | On  | [sic; no divider line]-^ |                |  |
| +-----+-----+-----+ |     |     |                          |                |  |

Bonus Points

| +-----+-----+-----+                        |     | +-----+ |  |
|--------------------------------------------|-----|---------|--|
| Bonus Points                               |     | SW4     |  |
| +-----+-----+-----+                        |     | +-----+ |  |
| 50,000 Pts. and after every 70,000 Points  | Off |         |  |
| *60,000 Pts. and after every 80,000 Points | On  |         |  |

+-----+-----+

[Page 6 begin]

v---[sic; transposed " " and ","]

2. Dip Switch No. 2 ,continues

Level of difficulty

| Option         | SW5 | SW6 | SW7 |
|----------------|-----|-----|-----|
| Very Easy      | off | off | off |
| Easy -1        | on  | off | off |
| " -2           | off | on  | off |
| " -3           | on  | on  | off |
| Average        | off | off | on  |
| Difficult*     | on  | off | on  |
| Very Difficult | off | on  | on  |
| Most Difficult | on  | on  | on  |

| Audio Attraction         | SW8 |
|--------------------------|-----|
| NO sound in attract mode | off |
| Sound in attract mode    | on* |

3. Dip Switch No. 3

[sic; no table heading/name]

| Music Mode | SW1 |
|------------|-----|
| Music Off  | Off |
| Music On   | On* |

\* Denotes Normal Settings