9/10/95 T. Franklin Bowen (mjrhavoc@clark.net or tfbowen@ingr.com) Originally typed up NOTES: + means `Suggested factory setting' Mat Mania Memetron, 1985 (copyright Taito, licensed by Technos, distributed by Memetron) Mat Mania Option Switch Settings _____ DIP Switch 1 Settings 1 2 3 4 5 6 7 8 Option _____ * Coin A Off Off 1 Coin - 1 Play + On Off 1 Coin - 2 Play Off On 1 Coin - 3 Play On On 2 Coin - 1 Play * Coin B Off Off 1 Coin - 1 Play + On Off 1 Coin - 2 Play Off On 1 Coin - 3 Play On On 2 Coin - 1 Play * Sound for Demonstration Off Sound + On Not Sound * TV Screen _____ Off Table type use On Up-right use + * Check Program Off OFF + On ON On Don't Touch + DIP Switch 2 Settings 1 2 3 4 5 6 7 8 Option

* Degree of Difficulty

Off Off D D D D D Normal
On Off O O O O O O O | +
Off On N N N N N N V
On On ' ' ' ' ' ' ' Difficult
T T T T T T

U U U U U U U
S S S S S S S
E E E E E E