



Nichibutsu

MOON CRESTA

OPERATOR ADJUSTMENTS

● V.R. ①

V.R. for the adjustment of sound volume. It will become smaller in turning it to the arrow-mark.


● SW. ②



DESCRIPTION	SW. POSITION					
Extended ROCKET score	1	2	3	4	5	6
30000 pts.	<u>OFF</u>					
50000 pts.	ON					
Instructions						
Japanese	OFF					
English	<u>ON</u>					
Coinage						
(Selector 1)						
1Coin/1play		<u>OFF</u>	<u>OFF</u>			
2Coin/1play		ON	OFF			
3Coin/1play		OFF	ON			
4Coin/1play		ON	ON			
(Selector 2)						
1Coin/1play				<u>OFF</u>	<u>OFF</u>	
1Coin/2plays				ON	OFF	
1Coin/3plays				OFF	ON	
FREE PLAY				ON	ON	

Note: ● Switch adjustment have to be done after disconnect the power supply.

● Switches are set as under-lined position when the machine is shipped.



Nihon Bussan Co., Ltd.

Made in Japan