

-----  
-  
-----  
Name Of Game:       Ms. Pac-Man                               Manuf: Midway Mfg. Co.  
-----  
-  
-----

Typed By:           James R. Twine                           Email: jtwine@prodigy.com  
-----  
-  
-----

Notes:

- 1) Facing the board, with edge connector to the left, the option DIP switched are located at the upper left of the board.
  - 2) Auto. Rack Advance can be attached to a button. This will allow you to skip a level at the push of a button.
  - 3) Freeze Video can be connected to a switch. This will allow you to pause the game at the push of a button.
- -  
-----

Option	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Free Play	ON	ON						
1 Coin   1 Credit	OFF	ON						
1 Coin   2 Credits	ON	OFF						
2 Coins   1 Credit	OFF	OFF						
1 Ms. Pac-Man Per Game			ON	ON				
2 Ms. Pac-Man Per Game			OFF	ON				
3 Ms. Pac-Man Per Game			ON	OFF				
5 Ms. Pac-Man Per Game			OFF	OFF				
Bonus Player @ 10000 Pts					ON	ON		
Bonus Player @ 15000 Pts					OFF	ON		
Bonus Player @ 20000 Pts					ON	OFF		
No Bonus Players					OFF	OFF		

```

      |
-----|-----|-----|-----|-----|-----|-----|-----
|-
----|
Auto. Rack Advance (Skip) |      |      |      |      |      |      | ON  |
      |
Normal                    |      |      |      |      |      |      | OFF |
      |
-----|-----|-----|-----|-----|-----|-----|-----
|-
----|
Freeze Video (Pause)     |      |      |      |      |      |      |      |
ON |
Normal                   |      |      |      |      |      |      |      |
OFF |
-----
-
-----
```