

Typed by Adrian Purser (24th MAY 1998)
ade@shadys.demon.co.uk

These switch settings are the results testing the switch settings on the pcb. I do not have access to the manual.

SW1

DIP SW1 Settings	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
CREDIT SETTINGS								
1 Coin/1 Credit	off	off	off					
1 Coin/2 Credits	on	off	off					
1 Coin/3 Credits	off	on	off					
2 Coins/1 Credit	on	on	off					
1 Coin/4 Credit	off	off	on					
3 Coins/1 Credit	on	off	on					
4 Coins/1 Credit	off	on	on					
1 Coin/1 Credit	on	on	on					
STARTING CREDIT								
2 Credit Start/1 Continue						on		
1 Credit Start/1 Continue						off		
SCREEN FLIP								
Screen Flip On							on	
Screen Flip Off							off	

SW2

DIP SW2 Settings	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
DIFFICULTY								
Normal	off	off						
Easy	off	on						
Hard	on	off						
Very Hard	on	on						
NUMBER OF FIGHTERS								
3			off	off				
4			off	on				
2			on	off				
1			on	on				
SOUND IN DEMO								
Yes						off		
No						on		
MODE								
Normal (Game)							off	
Test							on	