

# RYGAR DIP SWITCH SETTINGS

Typed in by pbardis@uoft02.utoledo.edu

disclaimer: blah blah not my fault blah use at your own blah risk  
blah blah

		DIP SWITCH 1							
Setting	Value	1	2	3	4	5	6	7	8
Coin 1	1 coin 1 play	Off	Off	*					Off
	2 coins 1 play	On	Off						
	1 coin 2 plays	Off	On						
	1 coin 3 plays	On	On						
Coin 2	1 coin 1 play			Off	Off				
	2 coins 1 play			On	Off				
	1 coin 2 plays			Off	On				
	1 coin 3 plays			On	On				
Number of Rygar	3					Off	Off		
	4					On	Off		
	5					Off	On		
	2					On	On		
Type	Cocktail							Off	
	Upright							On	

(\*=recommended operation)

		DIP SWITCH 2							
Setting	Value	1	2	3	4	5	6	7	8
Extra Rygar	50K-20K 500K	Off	Off	Off	Off				
	100K-300K 600K	On	Off						
	200K-500K	Off	On						
	100K	On	On						
Difficulty Levels	Normal				*	Off	Off		
	Difficult 1				#	On	Off		
	Difficult 2					Off	On		
	Difficult 3					On	On		
Playing Time	Normal							Off	
	2P additional play							On	
Buy-In	Normal								Off
	Buy-In								On

(\*=This difficulty setting is recommended for "street" operation.  
After 2 weeks of operation, it is recommended to adjust the difficult  
to difficulty 1 by turning SW 5 on.)

(#=This difficulty setting is recommended for "arcade" operation.  
After 2 weeks of operation, it is recommended to adjust the difficult  
to difficulty 2 by turning SW 5 off and SW 6 to on.)

Notes: buy-in available only up to round 20 (of 27)

: 2P additional play lets 2nd player begin play (from round 1)  
while  
player 1 is playing