

S.P.Y. (Special Project Y)
Konami, 1989

S.P.Y.
Option Switch Settings

DIP Switch No. 1 Settings
1 2 3 4 5 6 7 8 Option

				Coin Switch No. 1			

Off	Off	Off	Off	1	Coin	1	Credit*
On	Off	Off	Off	1	Coin	2	Credits
Off	On	Off	Off	1	Coin	3	Credits
On	On	Off	Off	1	Coin	4	Credits
Off	Off	On	Off	1	Coin	5	Credits
On	Off	On	Off	1	Coin	6	Credits
Off	On	On	Off	1	Coin	7	Credits
On	On	On	Off	2	Coins	1	Credit
Off	Off	Off	On	2	Coins	3	Credits
On	Off	Off	On	2	Coins	5	Credits
Off	On	Off	On	3	Coins	1	Credit
On	On	Off	On	3	Coins	2	Credits
Off	Off	On	On	3	Coins	4	Credits
On	Off	On	On	4	Coins	1	Credit
Off	On	On	On	4	Coins	3	Credits
On	On	On	On				Free Play

				Coin Switch No. 2				

	Off	Off	Off	Off	1	Coin	1	Credit*
	On	Off	Off	Off	1	Coin	2	Credits
	Off	On	Off	Off	1	Coin	3	Credits
	On	On	Off	Off	1	Coin	4	Credits
	Off	Off	On	Off	1	Coin	5	Credits
	On	Off	On	Off	1	Coin	6	Credits
	Off	On	On	Off	1	Coin	7	Credits
	On	On	On	Off	2	Coins	1	Credit
	Off	Off	Off	On	2	Coins	3	Credits
	On	Off	Off	On	2	Coins	5	Credits
	Off	On	Off	On	3	Coins	1	Credit
	On	On	Off	On	3	Coins	2	Credits
	Off	Off	On	On	3	Coins	4	Credits
	On	Off	On	On	4	Coins	1	Credit
	Off	On	On	On	4	Coins	3	Credits
	On	On	On	On				Void

DIP Switch No. 2 Settings
1 2 3 4 5 6 7 8 Option

Number of Lives

Off Off
On Off
Off On
On On

2
3*
5
7

Bonus Life

points Off Off
On Off
points* Off On
On On

At 10,000 points, then every 20,000
At 20,000 points, then every 30,000
At 20,000 points only**
At 30,000 points oonly

Difficulty of the Game

Off Off
On Off
Off On
On On

Easy
Normal*
Difficult
Very Difficult

Sound in Attractive Mode

Off Off
On On*

(SW3 is not used)

DIP Switch No. 3 Settings

1 2 3 4

Option

Video Screen Flip

Off
On

Normal*
Upside Down

Change of Mode

Off
On

Game*
Test

Continuation

Off
On

Unlimited*
5 times per player

(SW2 is not used)

* indicated recommended settings

** original manual listed this as a default switch setting, but
someone
corrected it by hand