

Spectar
Exidy, 1980

Spectar
Option Switch Settings

DIP Switch Settings								Option
1	2	3	4	5	6	7	8	
								Game Type

Off								Upright
On								Cocktail Table
								Top This Score

On								Credit awarded for topping score
Off								Extended play for topping score
								Credits Per Coin

Off Off								1 Coin 2 Credits
Off On								1 Coin 1 Credit
On Off								2 Coins 1 Credit
								For English Coins Only

On Off Off								1 10-pence Coin 1 Credit
								1 50-pence Coin 6 Credits
Off Off Off								2 10-pence Coins 1 Credit
								1 50-pence Coin 3 Credits
								Number of Turns

Off Off								2 Ships
On Off								3 Ships
Off On								4 Ships
On On								5 Ships
								Type of Coins

Off								U.S. and other
On								English coins

Language Selection:

To select the language, pull out the logic board. It is set low on the far right side if you are standing behind the game cabinet.

Place the logic board with the component side up, and the biggest connector

closest to you.

Now find location 8E, and look for two small squares, with two small circles above them. There should be a small wire or pin between each square and circle.

Depending on the language selection you desire, you will need to make an incision using an exacto knife at this location between the square and the circle. You only need to make a small "V" cut into the wire.

For English, no cutting is needed

For French, cut only LNG0 (pin #8E-8)

For German, cut only LNG1 (pin #8E-7)

For Spanish, cut both LNG0 and LNG1 (pins #8E-7 and 8E-8)