

STREET FOOTBALL - 1986 BALLY/SENTE
typed in by steven prendergast (2084@sgi.net) from the conversion
manuals. your milage may vary!

DIP SWITCH "G1"

	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
GAME TIME - 3:30	OFF	OFF	OFF		XX	XX	XX	
GAME TIME - 3:00	ON	OFF	OFF		XX	XX	XX	
GAME TIME - 2:40	OFF	ON	OFF		XX	XX	XX	
GAME TIME - 2:20	ON	ON	OFF		XX	XX	XX	
GAME TIME - 2:00	OFF	OFF	ON		XX	XX	XX	*
GAME TIME - 1:50	ON	OFF	ON		XX	XX	XX	
GAME TIME - 1:40	OFF	ON	ON		XX	XX	XX	
GAME TIME - 1:30	ON	ON	ON		XX	XX	XX	
1 OR 2 PLAYER / CREDIT				OFF	XX	XX	XX	
1 PLAYER / CREDIT				ON	XX	XX	XX	*
NO ATTRACT SOUNDS					XX	XX	XX	OFF *
ATTRACT SOUNDS					XX	XX	XX	ON

DIP SWITCH "H1"

	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
FREE PLAY	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN / 1 CREDIT	ON	ON						*
1 COIN / 2 CREDITS	OFF	ON						
2 COINS / 1 CREDIT	ON	OFF						
3 COINS / 1 CREDIT	OFF	OFF						
NO BONUS COINS			ON	ON	ON			*
2 COINS ADDS 1 BONUS COIN			OFF	ON	ON			
3 COINS ADDS 1 BONUS COIN			ON	OFF	ON			
4 COINS ADDS 1 BONUS COIN			OFF	OFF	ON			
4 COINS ADDS 2 BONUS COINS			ON	ON	OFF			
5 COINS ADDS 1 BONUS COIN			OFF	ON	OFF			
5 COINS ADDS 2 BONUS COINS			ON	OFF	OFF			
5 COINS ADDS 3 BONUS COINS			OFF	OFF	OFF			
LEFT COIN MECH X1						ON		*
LEFT COIN MECH X2						OFF		
RIGHT COIN MECH X1							ON	ON *
RIGHT COIN MECH X4							OFF	ON
RIGHT COIN MECH X5							ON	OFF
RIGHT COIN MECH X6							OFF	OFF

* INDICATES FACTORY RECOMMENDED SETTINGS