

Typed by Franklin Bowen (bowens@erols.com or tfbowen@ingr.com)
7/24/96

TRON SWITCH SETTINGS (Midway, 1982)

```
-----  
  
-----  
  
-----  
                                TRON  
                                ----  
                                OPTION SWITCH SETTINGS  
                                -----  
  
-----  
-----  
-----  
//////////////// SWITCH NO. 1 - AT B3 - LOCATED ON SOUND I/O P.C. BOARD  
////////////////  
-----  
-----  
                                | SW#1 SW#2 SW#3 SW#4 SW#5 SW#6 SW#7 SW#8  
SW#9 SW#10  
  
|-----  
    2 COIN METERS                | ON                NOT  NOT  NOT  NOT  NOT  
NOT  
    1 COIN METER                 | OFF                USED  USED  USED  USED  USED  
USED  
-----  
|-----  
    MINI / UPRIGHT               | ON  
    COCKTAIL TABLE             | OFF  
-----  
|-----  
    BUY IN ALLOWED               | ON  
    NO BUY IN                   | OFF  
-----  
|-----  
    FREEZE VIDEO                 |  
ON  
    NORMAL OPERATION            |  
OFF  
-----  
-----  
-----  
//////////////// SWITCH NO. 3 - AT D14 - LOCATED ON SOUND I/O P.C. BOARD  
////////////////  
-----  
-----  
-----  
                                | SW#1 **SW#2 **SW#3 **SW#4  
                                |-----  
    NORMAL OPERATION            | OFF  
    SOUND I/O DIAGNOSTIC MODE   | ON  
-----
```

NORMAL OPERATION	OFF
RAM/ROM TEST	ON
INDICATES TEST RESULTS VIA	
YELLOW L E D ON SOUND I/O	
BOARD: FAST FLASH = BAD ROM	
SLOW FLASH = BAD RAM	

NORMAL OPERATION	OFF
OSCILLATOR TEST	ON

NORMAL OPERATION	OFF
FILTER TEST	ON

** NO EFFECT IF SW#1 OR SWITCH NO. 3 IS IN THE "OFF" POSITION.

THE REMAINDER OF TRON'S MOST COMMON OPTION SETTINGS ARE CONDUCTED DURING THE MACHINE SETUP PORTION OF THE SELF-TEST MODE. SIMPLY FOLLOW THE ON-SCREEN INSTRUCTIONS TO MAKE ANY ADJUSTMENTS YOU FEEL ARE NECESSARY.