

* From: I091461@maine.maine.edu (Tom Nezwek)

Zaxxon Dip Switch Settings

Switch Bank #1 My Defaults: SW1 SW2 SW3 SW4 SW5 SW6 SW7
SW8

ON ON ??? ??? ON ON ON
OFF

SW #1	SW #2	(Bonus Ship)	SW #5	SW #6
ON	ON	AT 10,000 *	ON	ON
ON	OFF	AT 20,000	ON	OFF
OFF	ON	AT 30,000	OFF	ON
OFF	OFF	AT 40,000	OFF	OFF

SW #7		SW #8
ON	Sound On *	ON
OFF	Sound Off	OFF

Switch Bank #2 My Defaults: SW1 SW2 SW3 SW4 SW5 SW6 SW7
SW8

ON ON ??? ??? ON ON ON
OFF

SW #1	SW #2	SW #3	SW #4	SW #5	SW #6	SW #7	SW #8	(Coin Mech A/B)
ON	ON	ON	ON	ON	ON	ON	ON	4 Coins 1 Play
ON	ON	ON	OFF	ON	ON	ON	OFF	3 Coins 1 Play
ON	ON	OFF	ON	ON	ON	OFF	ON	2 Coins 1 Play
ON	ON	OFF	OFF	ON	ON	OFF	OFF	1 Coin 1 Play
ON	OFF	ON	ON	ON	OFF	ON	ON	* 1 Coin 2 Plays
ON	OFF	ON	OFF	ON	OFF	ON	OFF	1 Coin 3 Plays
ON	OFF	OFF	ON	ON	OFF	OFF	ON	1 Coin 4 Plays
ON	OFF	OFF	OFF	ON	OFF	OFF	OFF	1 Coin 5 Plays
OFF	ON	ON	ON	OFF	ON	ON	ON	1 Coin 6 Plays
OFF	ON	ON	OFF	OFF	ON	ON	OFF	2 Coins 1 Play
								4 Coins 2 Plays
								5 Coins 3 Plays
								6 Coins 4 Plays
OFF	ON	OFF	ON	OFF	ON	OFF	ON	2 Coins 1 Play
								4 Coins 3 Plays
OFF	ON	OFF	OFF	OFF	ON	OFF	OFF	1 Coin 1 Play
								2 Coins 2 Plays
								3 Coins 3 Plays
								4 Coins 4 Plays
								5 Coins 6 Plays
OFF	OFF	ON	ON	OFF	OFF	ON	ON	1 Coin 1 Play
								2 Coins 2 Plays
								3 Coins 3 Plays
								4 Coins 5 Plays
OFF	OFF	ON	OFF	OFF	OFF	ON	OFF	1 Coin 1 Play
								2 Coins 3 Plays
OFF	OFF	OFF	ON	OFF	OFF	OFF	ON	1 Coin 2 Plays

OFF OFF OFF OFF OFF OFF OFF OFF

2 Coins	4 Plays
3 Coins	6 Plays
4 Coins	8 Plays
5 Coins	11 Plays
1 Coin	2 Plays
2 Coins	4 Plays
3 Coins	6 Plays
4 Coins	9 Plays