

This document has been downloaded from:



The largest resource for amusement machines
documentation on the world wide web!



FLIPPERSPILL.COM

Konami inc.
Century inc.

CIRCUS CHARLIE™



SERVICE MANUAL

901-2169

CIRCUS CHARLIE
OPTIONAL DIP SWITCH SETTINGS

A. Dip Switch No.1 (8P Dip Switch)

Credits

Coin	Plays	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
1	1	Off	Off	Off	Off	Off	Off	Off	Off
1	2	On	Off	Off	Off	On	Off	Off	Off
1	3	Off	On	Off	Off	Off	On	Off	Off
1	4	On	On	Off	Off	On	On	Off	Off
1	5	Off	Off	On	Off	Off	Off	On	Off
1	6	On	Off	On	Off	On	Off	On	Off
1	7	Off	On	On	Off	Off	On	On	Off
2	1	On	On	On	Off	On	On	On	Off
2	3	Off	Off	Off	On	Off	Off	Off	On
2	5	On	Off	Off	On	On	Off	Off	On
3	1	Off	On	Off	On	Off	On	Off	On
3	2	On	On	Off	On	On	On	Off	On
3	4	Off	Off	On	On	Off	Off	On	On
4	1	On	Off	On	On	On	Off	On	On
4	3	Off	On	On	On	Off	On	On	On
Free Play		On	On	On	On	On	On	On	On

B. Dip Switch No.2 (8P Dip Switch)

1. Number Of Clowns

Number	SW1	SW2
☐ 3	Off	Off
4	On	Off
5	Off	On
7	On	On

2. Game Type

Style	SW3	Players
Table	Off	1 or 2 Players
Upright	On	Only 1 Player

3. Bonus Points Setting

First	And Every	SW4	SW5
☐ 20,000	70,000	Off	Off
30,000	80,000	On	Off

B. Dip Switch No.2 (continues)

4. Play Difficulty

Option	SW6	SW7
Easy	Off	Off
☐ Normal	On	Off
Hard	Off	On
Difficult	On	On

5. Audio Attraction

Sound Mode	SW8
No Sound In Attract Mode	Off
☐ Sound In Attract Mode	On

☐ Denotes Normal Settings




FIGURE 13

				TOLERANCES				HIALEAH, FLORIDA 33014			
				Unless Otherwise Specified							
				FRACTIONS	± 1/32			NAME			
				DECIMALS 2 PL	± .015			CPU HARNESS-CIRCUS CHARLIE, C/T			
				DECIMALS 3 PL	± .005			MATERIALS			
				HOLES	+ .003			HEAT TREAT.			
				ANGLES	± 1/2°			FINISH			
				SHT. MET BENDS	± 2°			DWN			
REV.	ECN	REVISION	BY	DATE	SCALE	PART NO.	REV.	DATE	SCALE	PART NO.	REV.
A	4041-01	CHANGED GRAY WIRE TO BROWN, CHANGED BROWN WIRE TO GRAY. FROM 24" TO 18". GRAY FROM 24" TO 18".	MSJ	12-28-83	1/2"	008-4930	A				

