

# CONNECTING DIAGRAM

SOLDER SIDE			PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	H	7	
	J	8	
	K	9	
SPEAKER(-)	L	10	SPEAKER(-)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNE	P	13	VIDEO BLUE
SERVICE	R	14	VIDEO GND
	S	15	
COIN 2	T	16	COIN 1
2P START	U	17	1P START
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH S/W 1	Z	22	1P PUSH S/W 1
2P PUSH S/W 2	a	23	1P PUSH S/W 2
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND

# SUPER VOLLEY BALL

## COIN / CREDIT OPTION SWITCH SETTING

DIP SW #1

OPTION	COIN 1				COIN 2			
	1	2	3	4	5	6	7	8
1 COIN 1 CREDIT	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN 1 CREDIT	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
2 COINS 3 CREDITS								
1 COIN 1 CREDIT	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
2 COINS 2 CREDITS								
3 COINS 3 CREDITS								
4 COINS 5 CREDITS								
1 COIN 1 CREDIT	ON	ON	OFF	OFF	ON	ON	OFF	OFF
2 COINS 2 CREDITS								
3 COINS 3 CREDITS								
4 COINS 4 CREDITS								
5 COINS 6 CREDITS								
1 COIN 6 CREDITS	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
2 COINS 1 CREDIT	ON	OFF	ON	OFF	ON	OFF	ON	OFF
4 COINS 2 CREDITS								
5 COINS 3 CREDITS								
6 COINS 4 CREDITS								
2 COINS 3 CREDITS	OFF	ON	ON	OFF	OFF	ON	ON	OFF
1 COIN 2 CREDITS	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
1 COIN 3 CREDITS	ON	OFF	OFF	ON	ON	OFF	OFF	ON
1 COIN 4 CREDITS	OFF	ON	OFF	ON	OFF	ON	OFF	ON
1 COIN 5 CREDITS	ON	ON	OFF	ON	ON	ON	OFF	ON
2 COINS 1 CREDIT	OFF	OFF	ON	ON	OFF	OFF	ON	ON
3 COINS 1 CREDIT	ON	OFF	ON	ON	ON	OFF	ON	ON
4 COINS 1 CREDIT	OFF	ON	ON	ON	OFF	ON	ON	ON

## OPTION SWITCH SETTING

DIP SW #2

OPTION		1	2	3	4	5	6	7	8
PLAY TIME	3 MIN - 1.5 MIN	OFF					OFF		OFF
	2 MIN - 1 MIN	ON					OFF		OFF
2P	2 P 7 - 7		OFF	OFF			OFF		OFF
	2 P 9 - 9		ON	OFF			OFF		OFF
START SCORE	2 P 5 - 5		OFF	ON			OFF		OFF
	2 p 0 - 0		ON	ON			OFF		OFF
1P	1 P 11-11				OFF	OFF	OFF		OFF
	1 P 10-11				ON	OFF	OFF		OFF
START SCORE	1 p 9-11				OFF	ON	OFF		OFF
	1 p 10-10				ON	ON	OFF		OFF
DEMOSOUND	OFF						OFF	OFF	OFF
	ON						OFF	ON	OFF

